

MOOG

VIDEOLARM

© 2012, Moog Videolarm, Inc. All Rights Reserved



R360-IV

Embedded Ceiling Mount with 360° Panomorph Lens and Camera Enclosure

www.moogvideolarm.com

Installation and Operation Instructions for the following model:

R360-IV The R360-IV indoor ceiling-mount housing features a flush plate that accommodates an ImmerVision *Enables*® panomorph lens and qualified box camera. The upper body, made of heavy 20 and 22-gauge steel and a white powder metal trim ring is plenum rated for fire resistant ceiling applications

Before attempting to connect or operate this product, please read these instructions completely.

81-IN5502
11-13-2012

IMPORTANT SAFEGUARDS

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with damp cloth.
- 7 Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
- 8 Cable Runs- All cable runs must be within permissible distance.
- 9 Mounting - This unit must be properly and securely mounted to a supporting structure capable of sustaining the weight of the unit.

Accordingly:

- a. The installation should be made by a qualified installer.
 - b. The installation should be in compliance with local codes.
 - c. Care should be exercised to select suitable hardware to install the unit, taking into account both the composition of the mounting surface and the weight of the unit.
- 10 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 - 11 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
 - 12 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
 - 13 Only use attachment/ accessories specified by the manufacturer.
 - 14 Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.
 - 15 Unplug this apparatus during lighting storms or when unused for long periods of time.
 - 16 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Be sure to periodically examine the unit and the supporting structure to make sure that the integrity of the installation is intact. Failure to comply with the foregoing could result in the unit separating from the support structure and falling, with resultant damages or injury to anyone or anything struck by the falling unit.

UNPACKING

Unpack carefully. Electronic components can be damaged if improperly handled or dropped. If an item appears to have been damaged in shipment, replace it properly in its carton and notify the shipper.

Be sure to save:


- 1 The shipping carton and packaging material.
They are the safest material in which to make future shipments of the equipment.
- 2 These Installation and Operating Instructions.

SERVICE

If technical support or service is needed, contact us at the following number:

TECHNICAL SUPPORT
AVAILABLE 24 HOURS
1 - 800 - 554 -1124

SAFETY PRECAUTIONS



The lightning flash with an arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk to persons.

Este símbolo se piensa para alertar al usuario a la presencia del "voltaje peligroso no-aislado" dentro del recinto de los productos que puede ser un riesgo de choque eléctrico.

Ce symbole est prévu pour alerter l'utilisateur à la présence "de la tension dangereuse" non-isolée dans la clôture de produits qui peut être un risque de choc électrique.

Dieses Symbol soll den Benutzer zum Vorhandensein der nicht-Isolier "Gefährdungsspannung" innerhalb der Produkteinschließung alarmieren die eine Gefahr des elektrischen Schlages sein kann.

Este símbolo é pretendido alertar o usuário à presença "di tensão perigosa non-isolada" dentro do cerco dos produtos que pode ser um risco de choque elétrico.

Questo simbolo è inteso per avvertire l'utente alla presenza "di tensione pericolosa" non-isolata all'interno della recinzione dei prodotti che può essere un rischio di scossa elettrica.



The exclamation point within an equilateral triangle is intended to alert the user to presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Este símbolo del punto del exclamation se piensa para alertar al usuario a la presencia de instrucciones importantes en la literatura que acompaña la aplicación.

Ce symbole de point d'exclamation est prévu pour alerter l'utilisateur à la présence des instructions importantes dans la littérature accompagnant l'appareil.

Dieses Ausruf Punktsymbol soll den Benutzer zum Vorhandensein de wichtigen Anweisungen in der Literatur alarmieren, die das Gerät begleitet.

Este símbolo do ponto do exclamation é pretendido alertar o usuário à presença de instruções importantes na literatura que acompanha o dispositivo.

Questo simbolo del punto del exclamation è inteso per avvertire l'utente alla presenza delle istruzioni importanti nella letteratura che accompagna l'apparecchio.



Limited Warranty for Moog Videolarm Products

Moog Videolarm warrants these products to be free from defects in material or workmanship as follows:

PRODUCT CATEGORY	PARTS \ LABOR
All Enclosures and Electronics*	Five (5) Years
Poles/PolEvators™/CamEvator	Three (3) Years
Warrior Series™/Q-View™/IR Illuminators	Five (5) Years
SView Series™	Five (5) Years **6 months if used in auto scan/tour operation
Controllers	Five (5) Years
Power Supplies	Five (5) Years
EcoKit	Three (3) Years
Accessory Brackets	Five (5) Years
Liberty Dome	Three (3) Years
*DeputyDome™, NiteTrac™, Igloo Dome, PurgeDome™	Three (3) Years **6 months if used in auto scan/tour operation

During the labor warranty period, to repair the Product, Purchaser will either return the defective product, freight prepaid, or deliver it to Moog Videolarm Inc. Decatur GA. The Product to be repaired is to be returned in either its original carton or a similar package affording an equal degree of protection with a RMA # (Return Materials Authorization number) displayed on the outer box or packing slip. To obtain a RMA# you must contact our Technical Support Team at 800.554.1124, extension 101. Moog Videolarm will return the repaired Product freight prepaid to Purchaser. Moog Videolarm is not obligated to provide Purchaser with a substitute unit during the warranty period or at any time. After the applicable warranty period, Purchaser must pay all labor and/or parts charges.

The limited warranty stated in these product instructions is subject to all of the following terms and conditions.

TERMS AND CONDITIONS

1. NOTIFICATION OF CLAIMS: WARRANTY SERVICE: If Purchaser believes that the Product is defective in material or workmanship, then written notice with an explanation of the claim shall be given promptly by Purchaser to Moog Videolarm. All claims for warranty service must be made within the warranty period. If after investigation Moog Videolarm determines the reported problem was not covered by the warranty, Purchaser shall pay Moog Videolarm for the cost of investigating the problem at its then prevailing per incident billable rate. No repair or replacement of any Product or part thereof shall extend the warranty period of the entire Product. The specific warranty on the repaired part only shall be in effect for a period of ninety (90) days following the repair or replacement of that part or the remaining period of the Product parts warranty, whichever is greater.

2. EXCLUSIVE REMEDY: ACCEPTANCE: Purchaser's exclusive remedy and Moog Videolarm's sole obligation is to supply (or pay for) all labor necessary to repair any Product found to be defective within the warranty period and to supply, at no extra charge, new or rebuilt replacements for defective parts.

3. EXCEPTIONS TO LIMITED WARRANTY: Moog Videolarm shall have no liability or obligation to Purchaser with respect to any Product requiring service during the warranty period which is subjected to any of the following: abuse, improper use, negligence, accident, lightning damage or other acts of God (i.e., hurricanes, earthquakes), modification, failure of the end-user to follow the directions outlined in the product instructions, failure of the end-user to follow the maintenance procedures recommended by the International Security Industry Organization, written in product instructions, or recommended in the service manual for the Product. Furthermore, Moog Videolarm shall have no liability where a schedule is specified for regular replacement or maintenance or cleaning of certain parts (based on usage) and the end-user has failed to follow such schedule; attempted repair by non-qualified personnel; operation of the Product outside of the published environmental and electrical parameters, or if such Product's original identification (trademark, serial number) markings have been defaced, altered, or removed. Moog Videolarm excludes from warranty coverage Products sold AS IS and/or WITH ALL FAULTS and excludes used Products which have not been sold by Moog Videolarm to the Purchaser. All software and accompanying documentation furnished with, or as part of the Product is furnished "AS IS" (i.e., without any warranty of any kind), except where expressly provided otherwise in any documentation or license agreement furnished with the Product. Any cost associated with removal of defective product and installation of replacement product is not included in this warranty.

4. PROOF OF PURCHASE: The Purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

DISCLAIMER OF WARRANTY

EXCEPT FOR THE FOREGOING WARRANTIES, Moog Videolarm HEREBY DISCLAIMS AND EXCLUDES ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO ANY AND/OR ALL IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND/OR ANY WARRANTY WITH REGARD TO ANY CLAIM OF INFRINGEMENT THAT MAY BE PROVIDED IN SECTION 2-312(3) OF THE UNIFORM COMMERCIAL CODE AND/OR IN ANY OTHER COMPARABLE STATE STATUTE. Moog Videolarm HEREBY DISCLAIMS ANY REPRESENTATIONS OR WARRANTY THAT THE PRODUCT IS COMPATIBLE WITH ANY COMBINATION OF NON-Moog Videolarm PRODUCTS OR NON-Moog Videolarm RECOMMENDED PRODUCTS PURCHASER MAY CHOOSE TO CONNECT TO THE PRODUCT.

LIMITATION OF LIABILITY

THE LIABILITY OF Moog Videolarm, IF ANY, AND PURCHASER'S SOLE AND EXCLUSIVE REMEDY FOR DAMAGES FOR ANY CLAIM OF ANY KIND WHATSOEVER, REGARDLESS OF THE LEGAL THEORY AND WHETHER ARISING IN TORT OR CONTRACT, SHALL NOT BE GREATER THAN THE ACTUAL PURCHASE PRICE OF THE PRODUCT WITH RESPECT TO WHICH SUCH CLAIM IS MADE. IN NO EVENT SHALL Moog Videolarm BE LIABLE TO PURCHASER FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION, REIMBURSEMENT OR DAMAGES ON ACCOUNT OF THE LOSS OF PRESENT OR PROSPECTIVE PROFITS OR FOR ANY OTHER REASON WHATSOEVER.



Electrical Specifications



Power 24VAC.
Class 2 Only

English



Energía 24VAC.
Clase 2 solamente

Español



Puissance 24VAC.
Classe 2 seulement

Français



Energie 24VAC.
Kategorie 2 nur

Deutsch



Poder 24VAC.
Classe 2 somente


Portuguese




Potere 24VAC.
Codice categoria 2 soltanto

Italiano

Contents of Box




1



Using the provided template, mark the ceiling tile for the cutout.

- Con la plantilla proporcionada, cortar el azulejo del techo para el agujero.
- En utilisant le calibre fourni, marquez la tuile de plafond pour le coupe-circuit.
- Mit der zur Verfügung gestellten Schablone kennzeichnen Sie die Decke Fliese für den Ausschnitt.
- Usando o molde fornecido, marque a telha do teto para o entalhe.
- Usando la mascherina fornita, contrassegni le mattonelle del soffitto per il ritaglio.


2



A box cutter or jigsaw can be used for cutting the circle.

- Un cortador o un rompecabezas de la caja se puede utilizar para cortar el círculo.
- Un coupeur ou une scie sauteuse de boîte peut être utilisé pour couper le cercle.
- Ein Kastenscherblock oder -tischlerbandsäge können für den Schnitt des Kreises benutzt werden.
- Um cortador ou um jigsaw da caixa podem ser usados cortando o círculo.
- Una taglierina o un jigsaw della scatola può essere utilizzato per il taglio del cerchio.

3



Place the housing in the tile and secure the outer tabs.

- Coloque la cubierta en el azulejo y asegure las lengüetas externas.
- Placez le logement dans la tuile et fixez les étiquettes externes.
- Legen Sie das Gehäuse in die Fliese und sichern Sie die äußeren Vorsprünge.
- Coloque a carcaça na telha e fixe as abas exteriores.
- Disponga l'alloggiamento nelle mattonelle ed assicuri le linguette esterne.

4



Connect the flex conduit to the housing.

- Conecte el conducto de la flexión con la cubierta.
- Reliez le conduit de câble au logement.
- Schließen Sie das Flexrohr an das Gehäuse an.
- Conecte a canalização do cabo flexível à carcaça.
- Collegli il condotto della flessione all'alloggiamento.


5



Add the safety wire to the can, connect to structural support.

- Agregue el cable de seguridad a la lata, conecte al soporte estructural.
- Ajouter le fil de sécurité à la boîte, se connecter à un soutien structurel.
- Fügen Sie den Sicherheitsdraht an der Dose, um strukturelle Unterstützung zu verbinden.
- Adicionar o fio de segurança para a lata, ligue para o suporte estrutural.
- Aggiungere il cavo di sicurezza alla lattina, connettersi a sostegno strutturale.


6



Install the camera on the fixed bracket and complete all wiring applications.

- Instale la cámara fotográfica en el soporte fijo y termine todos los usos del cableado.
- Installez l'appareil-photo sur la parenthèse fixe et accomplissez toutes les applications de câblage.
- Bringen Sie die Kamera am örtlich festgelegten Haltewinkel an und führen Sie alle Verdrahtung Anwendungen durch.
- Instale a câmera no suporte fixo e termine todas as aplicações da fiação.
- Installi la macchina fotografica sulla staffa fissa e completi tutte le applicazioni dei collegamenti.


7



Position the lens as shown.

- Coloque el lente como se muestra.
- Placez la lentille comme indiqué.
- Positionieren Sie das Objektiv wie abgebildet.
- Posicione a lente como mostrado.
- Posizionare la lente, come mostrato.


8



Make power and network connections.

- Asegúrese que la alimentación y las conexiones de red.
- S'assurer que l'alimentation et les connexions réseau.
- Machen Sie Strom-und Netzwerkanschlüsse.
- Faça poder e conexões de rede.
- Accertarsi che l'alimentazione e le connessioni di rete.


9



Center the lens/camera in the housing.

- Centro de la lente / cámara en la carcasa.
- Centre de la lentille / caméra dans le boîtier.
- Zentrieren Sie das Objektiv / Kamera im Gehäuse.
- Centro da lente / máquina fotográfica na carcaça.
- Centrare l'obiettivo / fotocamera nella custodia.


10



Tighten the cameras thumb screws.

- Apriete los tornillos de mariposa cámaras.
- Serrer les vis de caméras pouce.
- Ziehen Sie die Kameras Rändelschrauben.
- CAperte os parafusos de câmeras polegar.
- Serrare le viti di pollice telecamere.


11



Install the trim ring assembly as shown.

- Instale el conjunto del anillo de ajuste como se muestra.
- Installez l'ensemble de garniture comme indiqué.
- Installieren Sie den Zierring Anordnung gezeigt.
- Installare il gruppo assetto anello come mostrato in figura.
- Serrare le viti di pollice telecamere.

12



Tabs should align with cutouts as shown.

- Tabs debe alinearse con cortes como se muestra.
- Les onglets doivent être alignés avec des découpes comme indiqué.
- Tabs sollten mit Ausschnitten auszurichten, wie dargestellt.
- Tabs deve alinhar com recortes, como mostrado.
- Le schede devono essere allineati con ritagli come mostrato.




Push in the trim ring until tabs snap in place.

- Empuje el anillo de ajuste hasta que las lengüetas encajen en su lugar.
- Poussez la garniture jusqu'à ce que les languettes s'enclenchent en place.
- Drücken Sie den Zierring bis die Halterungen einrasten.
- Empurre o anel de acabamento até que as abas encaixem no lugar.
- Spingere l'anello di chiusura finché le linguette scattano in posizione.

Replacement Parts List

R360-IV



	DESCRIPTION	REPLACEMENT PARTS NUMBER
1	PRVL4267	TRIM RING
2	RP30VL2204	MR7 CLIPS
3	RP30VL4270	CAMERA BRACKET
4	RP90BTW04	WING BOLTS (3)
5	RP30VL2463	SPRING CLIP and BOLT
6	RP30VL4266	RECESSED CAN ASSEMBLY

Product Registration/Warranty

Thank you for choosing Moog Videolarm. We value your patronage and are solely committed to providing you with the highest quality products available and superior customer service.

Should a problem arise, rest assured that Moog Videolarm stands behind its products by offering impressive 3 Year and 5 Year warranties, depending on the product purchased. See full warranty details at www.moogvideolarm.com/technical-support/warranty-plan/



Register Your Products Online

Please take a few moments to register your purchase via the Online Product Registration Form at:

www.moogvideolarm.com/technical-support/product-registration

Register your recent Moog Videolarm purchase and benefit from the following:

- Simple and Trouble-Free RMA process
- Receive product updates, and special promotion
- Eliminate the need to archive original purchase documents:
Receipts, Purchase Orders, etc...